

# UNCxxx - Remove redundant text on capacity holdings and offtake rights

## Remove CFLAT/24 Maximum Shipper Offtake Rate

Key: *redundant* / *possibly redundant and remove for consistency* / *retain*

### 3.10.1 A:

- (a) *Shipper User is not entitled to offtake gas from an NTS Supply Point or NTS Connected System Exit Point;*
- (b) *DNO User is not entitled to offtake gas from the upstream System at an Inter-System Offtake at a rate which exceeds the maximum permitted rate in accordance with paragraph 3.10.2 or 3.10.3 (as applicable), and shall take all reasonable steps to ensure that gas is not offtaken at such a rate.*

### 3.10.2 The maximum permitted rate in respect of:

- (a) *an NTS/LDZ Offtake, is a rate calculated as:  $(CFLAT / 24) + (C(M)FLEX / 4)$  where: CFLAT is the DNO User's NTS Exit (Flat) Capacity; C(M)FLEX is the magnitude of the DNO User's NTS Exit (Flexibility) Capacity;*
- (b) *an NTS Supply Point or a NTS Connected System Exit Point, is a rate calculated as:  $(CFLAT / 24)$  where CFLAT is the Shipper User's NTS Exit (Flat) Capacity.*

## UNCxxx - Remove redundant text on capacity holdings and offtake rights

### Remove No Obligation on NGT to Make Gas Available

**3.10.5 In the case of an NTS Exit Point National Gas Transmission will not be obliged under any provision of the Code to make gas available for offtake from the NTS by a User:**

*(a) at any time, at a rate which exceeds the maximum permitted rate (in accordance with paragraph 3.10.2);*

*(b) on any Day, in a quantity which exceeds the User's Fully Adjusted Available NTS Exit (Flat) Capacity;*

*(c) in the period between 06:00 hours and 22:00 hours on any Day, in a quantity which exceeds  $(NEFC + 16/24 * QD)$  (as those terms are defined in Section B3.13);*

**(d) at any time, at a rate which exceeds the Maximum NTS Exit Point Offtake Rate.**